



### Comet Driven Installation

1. Install 3/8-24 stud into the end of Albion input shaft using removable Loctite.
2. Slide keyed adapter and driven clutch onto Albion input shaft.
3. Align driven clutch to driver clutch.
4. Tighten set screw on top of Albion key.
5. Install 3/4" OD spacer onto shaft.
6. Install washer and 2 3/8-24 nuts. Lock nuts to each other allowing slight end play of driven clutch.